

Finofix

Electric stripping machine for fine copper magnet wire



Specification:

Electric desktop stripping machine for copper magnet wire from \varnothing 0,04 up to \varnothing 0,3 mm.
Put the wire top down between the rotating fibre-glass brushes.

After pull out forward wire is stripped.

Distance between brushes is adjustable with knurled screw.

Technical Data:

Material \varnothing	0,04 – 0,3 mm
Stripping length	endless
Voltage	230/50 V/Hz oder 115/60 V/Hz
Connected load	55 VA
Length	150 mm
Width	230 mm
High	170 mm
weigth	4,0 kg
brushes Nr.	127 soft
brushes Nr.	640 hard