

FUCHS STAR Un-enamelling manual electric machine



Description :

Easy handling device for un-enamelling of enamelled copper wires. The Fuchs Star works with motor 230V DC and is directly connected to 230V.

The three rotary cutting blades carbide head are mounted on the head and ajusts the speed, due to centrifugal force.

The variable control button allows precise setting of desired speed for each size of thread.

Application :

Insert the wire in the top, set the desired speed, press the Start button, then pull the thread slowly

Technical data:

Stripping lenght max.: 32 mm Power: 230 V Using: 18 watts Lenght: 170 mm Diameter: 50 mm Weight: 550 g

Тур 02	Ø0,2 to 1,5mm	Withdrawing of 3mm
Тур 03	Ø0,3 to 4,0mm	Stripping lenght max. 32mm