



IRON FOR LOST WAX WORK

“SHARP IRON”

GENERAL

“SHARP IRON” is a device especially designed for touch-up work, shaping and finishing in the areas of lost wax casting :



COMPOSITION

“SHARP IRON” is composed of :

- a special iron **power 12 to 20W** ensuring a significant reserve of temperature
- a removable tip annealed copper (so pliable) with diameter 3 mm.
- with a connector, depending on the type of generator used:
 - Stereo cable jack
 - Banana plugs dia 6
 - DIN plug



SPECIFICATIONS

- Power supply : 3 to 6 Volts max AC or DC
- Heating element coiled “high reliability”
- Stainless steel heating element
- Heat-resistant and lightweight handle
- Max temperature 200 to 400°C according to type of generator and his voltage
- Iron weight with tip: 25 g

OPTIONAL TIPS

On this iron, we can change the copper pliable tip by hard copper tips treated in NiCr (SEE BELOW)

	3603
	3602
	3604
	3616

Premier fabricant français pour l'industrie électronique

F.T.M. Technologies SEM - 78 rue Raymond Poincaré 92000 NANTERRE FRANCE

Tel : (33) 01 40 86 0 09 - Fax : (33) 01 40 86 16 45 - Web sites : www.semsoudage.com - www.ftm-technologies.com