

IRON FOR LOST WAX WORK

SPAT 55FCP

GENERAL

SPAT 55FCP is a device especially designed for touch-up work and finishing in the areas of lost wax casting, but also in works such as :



Cabinet making Fine arts Plasitc works Textile fabric Laboratories

SPAT 55FCP can also provide following applications:

Heating

Veneering, Spatulating,

Pasta, unpaste Cleaning....

...with a large selection of tips, nozzles and spatulas.

CONPOSITION

SPAT 55FCP iron includes :

- an iron **55W power** ensuring a significant reserve of temperature.
- a spatula tip 10x70 in aluminium.
- an iron-support

Optional: To increase the accuracy and quality of your work, this iron can be connected to the power regulator ref. **RP500** which allows operation over a wide range of temperatures from 0 to 300°c maxi.

TECHNICAL DATA

Iron

- Power supply 230V 55W
- Heating coiled element "high reliability"
- Stainless steel heating element
- Heat-resistant and lightweight handle
- Max temperature 350 to 400°c according to type of spatula
- Iron weight with tip: 200 g



