

Abfräsfix

electrical stripping machine
for varnished wires



The Abfräsfix is a electrical stripping machine for varnished wires. The wire is pushed into the rotating stripping-head up to the lengthstop. Thereby five blades are milling the varnish away. Strippinglength and -diameter are steplessly variable. For heavy workparts it is possible to use a flexible shaft. The machine will be delivered with blades of tool steel. For very strong varnish we can deliver blades of hard metall.

Technical Data:

Wire Ø:	0,8—5,0 mm or 5,0—8,0 mm
Stripping length:	up to 25mm (without lengthstop up to 35mm, max Ø 3mm)
Power supply:	230V, 50Hz or 115V, 60Hz
Driving speed:	2650 min ¹
Width:	110mm
Depth:	230mm
Height:	140mm
weighth:	4,5 kg