

Electric stripping machine for copper enamelled wires – ABRFRÄSFIX



The ABRFRÄSFIX is an automatic machine to strip enamelled wires. The wire is pushed into the rotary stripping head to the length stop. The five blades rotate around the wire removing enamel. The stripping length and the diameter are constantly variable. For all heavy duty works it is possible to use a flexible shaft.

The machine will be delivered with steel blades. For resistant enamels, we can provide tougher blades made of high strength steel.

Technical data	
Ø wire	0.8 – 5.0 mm or 5.0 – 8.0 mm
Stripping length	Up to 25 mm with stop (without stop up to 35 mm, max Ø 3 mm)
Mains supply	230 V / 50 Hz – 115 V / 60 Hz
Rotation speed	2650 min ⁻¹
Width	110 mm
Depth	230 mm
Height	140 mm
Weight	4.5 kg



Flexible axis



Cutting head



Steel blades

