

Manual stripping machine for enamelled round and flat wires ABISOBRUSH HQ 30 / HQ 35 P

Brush machine, used to remove enamel from 0.15 to 3 mm (HQ 30) and 1.5 to 6.00 mm (HQ 35 P) diameter wires round cables and also flats (1 to 6 mm with HQ 35 P).



The knurled screw allows the adjustment of the spacing of the brushes to ensure stripping to the correct diameter.

The wire must be inserted from the front or side and pulled backward.

Technical data	
Particularity HQ 30	
Ø for round wires	0.15 – 3.0 mm
Weight	1.9 kg
Mains supply	230 V / 50 Hz
Ø brushes	30 mm
Direction of rotation of the brushes	Opposite direction to avoid opposite tensions in the wire
Particularity HQ 35 P	
Ø for round and flat wires	1.5 – 6.0 mm 1 – 6 mm thickness
Weight	2.2 kg
Mains supply	230 V / 50 Hz
Ø brushes	35 mm
Direction of rotation of the brushes	Same direction of rotation



Spare brushes for HQ35P

Ø or thickness of wire	Brushes reference
For HQ 30	
Ø0.40 – 1.00 mm	130015
Ø0.60 – 1.50 mm	130020
Ø0.80 – 3.00 mm	130025
For HQ 35 P	
Ø1.50 – 2.50 mm	135015
Ø2.00 – 3.00 mm	135020
Ø2.50 – 4.00 mm	135025
Ø3.00 – 6.00 mm	135030