

## Stripping electric machine for the finest enameled copper wires - FINOFIX



Designed for wires from Ø 0.04 to Ø 0.3 mm.  
The spacing of the brushes is adjustable by a knurled screw.

- ✓ Easy to use
- ✓ Small compact device
- ✓ The wire to be stripped simply passes from the front or the top between the rotating fiberglass cones and is pulled backwards
- ✓ Two levels of hardness available for brushes

Technical data	
Ø wire	0.04 – 0.3 mm
Mains supply	230 V / 50 Hz or 115 V / 60 Hz
Power	55 VA
Length	150 mm
Width	230 mm
Height	170 mm
Weight	4 kg
Brushes	N°127 soft / N°640 hard
Unlimited stripping length	



Soft brush No 127



Hard brush No 640