

Electric hand stripping machine for copper enamelled wires – FUCHS STAR



Very handy device for stripping enamelled copper wires. The Fuchs Star is connected directly to the 230 V mains (or 110 V).

The three rotating cutting blades (carbide heads) are mounted on the head and are adjusted by speed, due to the centrifugal force. The control knob allows precise adjustment of the desired speed for each wire size.

Insert the wire into the stripping head, set the desired speed, press the start button and pull the wire slowly.



*Interchangeable head
for Fuchs Star*

Technical data	
Mains supply	230 V 50 Hz – 110 V 60 Hz
Power	18 W
Length	170 mm
Diameter	50 mm
Weight	550 g
Stripping length max	32 mm
Stripping distance min	3 mm
Type 02	Ø 0.2 to 1.5 mm
Type 03	Ø 0.3 to 4.0 mm



Fuchs Star complete machine