

Pneumatic hand stripping machine for flat copper wire - Rectangular wire stripper



Suitable to remove the enamel from rectangular wires of thickness : min 2 mm - max 12 mm.

Insert the wire to be stripped in the stripper head between the two blades and rotate the tool so that the two blades rest against it. Start the grinding machine and slide the tool on the wire until fully stripped. Repeat the operation on the other sides.

- ✓ Easy handling
- ✓ Small compact device
- ✓ The speed is set directly on the device

Technical data	
Max stripping width	12 mm
Length	310 mm
Diameter	50 mm
Weight	1 230 g



Head of the machine



Overview of the two parts of the machine